

♦ Installation

- 1. Why does Smart ASOV automatically start filling when powered on?
- 2. Why doesn't Smart ASOV activate when the water level is below the sensor?
- 3. Can the Smart ASOV be used with unfiltered water?

Accessory

- 1. How to extend the cable length of the solenoid valve and power supply?
- 2. How to purchase accessories?

◆ Product Information

- 1. Does Smart ASOV have a failsafe mechanism?
- 2. What is the difference between Smart ASOV and Smart ATO Lite G2?



Why does Smart ASOV automatically start filling when powered on?

The Smart ASOV performs a one-time filling automatically when it is first powered on. If it detects water when powered on, it will go into standby mode.





Why doesn't Smart ASOV activate when the water level is below the sensor?

The Smart ASOV is designed for manual refilling. It will not automatically refill when the sensor detects no water.





> Can the Smart ASOV be used with unfiltered water?

No.

Filtered water is required to prevent sediment from clogging the solenoid valve.

Do not install the solenoid valve before your filtration system or without a filtration system.





How to extend the cable length of the solenoid valve and power supply?

You can use the extension cable. We have 6.7 ft (200 cm) and 16.7 ft (500 cm) available.

- Extension Cable of Power Adapter (200cm)
 http://autoaqua.com.tw/en/accessories/DC-212.html
- Extension Cable of Power Adapter (500cm)
 http://autoaqua.com.tw/en/accessories/DC-215.html
- Extension Cable of DC Refill Pump & Solenoid
 Valve (200cm)
 http://autoaqua.com.tw/en/accessories/DC-252.html
- Extension Cable of DC Refill Pump & Solenoid Valve (500cm) http://autoaqua.com.tw/en/accessories/DC-255.html







➤ How to purchase accessories?

Please contact our local distributors :

http://autoaqua.com.tw/en/distributors.html








Does Smart ASOV have a failsafe mechanism?

Yes.

Smart ASOV is equipped with failsafe sensor.

 Failsafe sensor: It serves as the main sensor to keep the Smart ASOV working properly.







➤ What is the difference between Smart ASOV and Smart ATO Lite G2?

	Smart ATO Lite G2	Smart ASOV
Refill Method Type	Automatic refill	Manual refill
Failsafe Sensor	~	*
Built-in QST	✓	×
Alarm (Buzzer / LED)	V / V	✓/ ×
Included Accessories	Smart ATO Lite G2 Controller Universal Power Adapter DC Pump Universal Tube Holder Siphon Break	Smart ASOV Controller Power Adapter DC Solenoid Valve RO Tubing Holder
	Tubing 6.5 feet (200 cm)	

^{*}Note: Smart ASOV is unable to automatically refill water. We suggest avoiding using it as an ATO.

